
Shaketune vs. Klipper

Comparison between the input shapers

Voron V2.4 350 - 3812



Printer Mods

- Stealth Burner
- Mellow Fly SB-2040 toolhead board
- Rapido v1
- 0.4 CHT
- Umbilical using igus cable (prefer 3do cable)
- Rama Idlers
- Pin Mod (xy joints and AB motor mounts)
- Hartk umbilical pass through
- Nevermore x2 on left and right side of build plate
- Mandala Rose Works build plate with magnets
- Mandala Rose Works Kinematic Kit
- TI backers (x and y)
- FlexTap (AndrewMcGr)

What is the difference

- Klipper uses a default damping ratio of 0.1 in the calculation of the shapers.
- Shaketune uses the damping ratio calculated from the measured graphs in the calculation of shapers.
- Both use the built-in TEST_RESONANCE macro to run.
- Thus, the major difference is how the shaper values are calculated

Belt Shaper


- Shaketune
 - Click "Belt Shaper Calibration" in mainsail
 - Files in mainsail in config files

Klipper

- https://www.klipper3d.org/Measuring Resonances.html#testing-custom-axes
- Commands (run individually in this order)
 - TEST_RESONANCES AXIS=1,1 OUTPUT=raw_data
 - TEST_RESONANCES AXIS=1,-1 OUTPUT=raw_data
 - ~/klipper/scripts/graph_accelerometer.py -c /tmp/raw_data_axis*.csv -o /tmp/resonances.png (ssh)
- Files in /tmp

BeltShaper with FlexTap

Frequency (hz)



Frequency (Hz)

Input Shaper

- Shaketune
 - Click "Axes Shaper Calibration" in mainsail
 - Files in mainsail in config files

Klipper

- https://www.klipper3d.org/Measuring Resonances.html#testing-custom-axes
- Commands (run individually in this order)
 - TEST RESONANCES AXIS=X
 - ~/klipper/scripts/calibrate_shaper.py /tmp/resonances_x_*.csv -o /tmp/shaper_calibrate_x.png (ssh)
 - TEST_RESONANCES AXIS=Y
 - ~/klipper/scripts/calibrate_shaper.py /tmp/resonances_y_*.csv -o /tmp/shaper_calibrate_y.png (ssh)
- Files in /tmp


Input Shaper = x (FlexTap)




INPUT SHAPER CALIBRATION TOOL


30/03/24 15:44:35 -- X axis

Square corner velocity: 5.0mm/s Max allowed smoothing: None










Input Shaper = y (FlexTap)

125

Frequency (Hz)


150

175




Prusa Slicer 2.7.2 setting

note: ext/int perimeter accel changes between prints




SCV=5.0

Filament Settings: KVP ABS



Line widths



- Note:
- Chamber preheated to 45 C (37 min)
- Chamber temp over total prints 57.5 C
- 0.2 layer height
- 0.44/0.46 int/ext perimeter width

ADXL settings

#Shaketune MZV

[input_shaper]

shaper_freq_x: 55.4

shaper_type_x: mzv

damping_ratio_x: 0.065

shaper_freq_y: 37.0

shaper_type_y: mzv

damping_ratio_y: 0.069

#Shaketune EI

[input_shaper]

shaper_freq_x: 67.2

shaper_type_x: ei

damping_ratio_x: 0.065

shaper_freq_y: 45

shaper_type_y: ei

damping_ratio_y: 0.069

#Klipper MZV


[input_shaper]


shaper_freq_x: 54.6

shaper_type_x: mzv

shaper_freq_y: 37.4

shaper_type_y: mzv





Let's push it

- 1) Increased accel to 4k on shaketune MZV
- 2) internal/external perimeter speed=250 Internal perimeter accel = 6000
- 3) Increased Max volumetric speed/flow from 24 to 30

external perimeter speed = 350 Internal perimter speed =325 Solid infill = 275 Solid infill accel = 6000

4) Increased max volumetric speed/flow from 30 to 35

External perimeter speed = 375
Internal perimeter speed = 390
Infill = 155
Top solid infill = 125
Gap fill =125
internal perimeters accel = 6000
Top solid infill accel = 6000
Solid infill accel = 8000
Infill accel = 8000

5) increased max volumetric speed/flow from 35 to 40
External perimeter speed = 435
Internal perimeter speed =450
Infill = 190
Solid infill = 350
External Perimeter accel = 7k
Top solid infill = 7k
Solid infill = 9k
Infill = 9k
Travel = 10k

Small perimeter = 70

What I settled For...

6) Kept max volumetric speed/flow at 40

Speeds

Internal perimeters = 250/125

External perimeters = 250/125

Small perimeters = 85

Infill = 190

Solid infill = 125

Top solid infill = 125

Travel = 300

Max print speed = 400

Accels

External perimeter accel = 4000 Internal perimeter accel = 4000

Top solid infill = 4000

Solid infill = 4000

Infill = 6000

Travel = 8,000

Filament

EM 0.94 to 1.05 to 0.95